# iLook Camera User manual



## 1.0 Key Features

- (1) Lightweight and smart design (2) 5.8G FPV wireless transmission
- (3) Low latency and long range FPV (4) Support output Micro SD card
- (5) Support G-2D brushless gimble (6) Support Video and Camera
- (7) Support wireless Video link to 5.8G radio / OSD device/iPhone/iPad
- (8) Support Walkera 5.8G DEVO F7 to send the live video directly to the transmitter's display

#### 2.0 Specifications

## (1) Video

b. FPS: 30 a. Video Resolution: HD 1280 x720P

c. Micro High Speed SD card: Max 32G d Video Format: AVI

f. Photo: 1,000,000 Pixels e. AV output QVGA 320x240 PAL/1Vp-p


#### (2) 5.8G wireless

a. 5.8G wireless image transmission b. FCC Bind B section: 4 channels

c. CF Bind B section: 8 channels. d. FCC Output Power ≤200mW

e. CE Output Power ≤25mW

## 3.0 Pictures illustration



#### 4.0 Transmitting channel selection

Note: When iLook camera transmission channel corresponds to transmitter video receiving channel, the transmitter can receive the video display, other channels appear blue screen.

#### 4.1 DEVO F7 Video Select

Press ENT to the Main Menu. Press UP or DN to move the cursor → to point to System Menu, press ENT to System Menu: Press UP or DN to move the cursor → to point to Video Select, press ENT to Video Select setting interface. Press R or L to select Active. Press DN to move the cursor → to point to Channel item, press R or L to make the Number change between 1 and 8. With the illook camera transmitting channel

1-8 channels could be chosen to receive the image signal, Press ENT to confirm and then press **FXT** to exit

| Video Seled | ct 7.4\ |
|-------------|---------|
| →Status     | Active  |
| Channel     | 1/8     |

| ١ | g chamio,  |     |      |
|---|------------|-----|------|
|   | Video Sele | ct  | 7.4V |
|   | Status     | Ac  | tive |
|   | →Channel   | 1/8 | 3    |

### 4.2 iLook(FCC/CE) camera transmitting channel selection

There are 8 different channels can be selected. You can choose the best frequency channel according to the image quality as bellow:



|             | _  |
|-------------|----|
| Channel     | 1  |
| code positi | on |

ON

1 2 3

Channel 5

code position



ON

1 2 3

Channel 6

code position

Π

Channel 2 code position



Channel 3 code position

ON



| ON |        |
|----|--------|
|    |        |
|    |        |
| 2  | 3      |
|    | ON<br> |

Channel 7 code position



code position

Note: Only transmitting channel 2, 4, 6, 8 are available for the iLook(FCC).

# 5.0 Video and Photo user guide

Note: MICOR SD card must be inserted to the iLook camera before connecting the power, and took off after disconnecting the power. (Recommend to use high speed SD card)

#### 5.1 Video instruction

# iLook Camera User manual



### (1) Manual Operation

Please first turn the Video/Photo Swich to , press and release the button, iLook camera starts to Video(the blue indicator keep flash); Press again and release, iLook camera stops video(The blue indicator keeps solid).

#### (2) Radio Operation

Please first turn the Video/Photo Swich to ■, turn the GEAR switch to "1" position within 1-2 seconds, then return to "0" position, iLook camera will start to video(the blue indicator keep flash); toggle the GEAR switch again, iLook camera stop video(The blue indicator keeps solid)

#### 5.2 Photo instruction

Please put the video/photo switch to , Press and release the button, iLook camera starts single phase (The blue indicator keeps solid), press again and release the button, and then take another picture.

#### 6.0 Connect Illustration

Note: The GEAR switch of the transmitter output port channel should be consistent with the receiver output port.

